

- * The entire door track and 100TDiS are set in above and separate to waterproofing. Therefore waterproofing must be completed first.
- * The included sill tray must be installed first as the door tracks are installed into tray of the 100TDiS.



This drawing is the intellectural property of STORMTECH Pty Ltd. Drawings are not to scale. Use dimensions shown.