

- * The entire door track and 65TDiS are set in above and separate to waterproofing. Therefore waterproofing must be completed first.
- * The included sub-sil tray must be installed first as the door tracks are installed into tray of the 65TDiS.
- * Refer to;

```
AS1428 Design for Access and Mobility AS4654 for waterproofing
```





This drawing is the intellectural property of STORMTECH Pty Ltd. Drawings are not to scale. Use dimensions shown.