65i40 TIMBER FLOOR/DECK

For 65ARi40, 65PHi40, 65PSi40, 65TRi40



When 65i40 is running parrallel to joist/bearer





When 65i40 is running perpendicular to joist/bearer



